

This Page Is Inserted by IFW Operations
and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

**As rescanning documents *will not* correct images,
please do not report the images to the
Image Problem Mailbox.**




Fig. 1




Fig. 2




Fig. 3





Fig. 4



Fin.




Fig. 8




Fig. 9




Fig. 10




Fig. 11




Fig. 12




Fig. 13




Fig. 15




Fig. 16



Fig. 17





Fig. 18



CLEAN MODE:

1. OVEN DOOR MUST BE CLOSED
2. SWITCH MUST INDICATE CLOSED/OPEN DOOR POSITION (LOW VOLTAGE)
3. SWITCH TO INDICATE LATCH POSITION - LOCKED/UNLOCKED
4. SWITCH TO DISABLE LIGHTS (INCANDES. OR HALOGEN OR OTHER)

Fig. 19




Fig. 20




Fig. 21




Fig. 22





Fig. 23A



S1 - SWITCH CONTACTS TO CLOSE WHEN
OVEN DOOR IS CLOSED

S2 - SWITCH CONTACTS TO CLOSE WHEN
OVEN DOOR IS CLOSED

S3 - SWITCH CONTACTS CLOSE WHEN
IN LOCK (CLEAN MODE) POSITION

Fig. 23B